

Note bolt thread area should be on outside of hoist

If this print has colored cables they are for easier understanding of how they are strung. Cables from the factory are colored too. They won't all match to below colors.


ASSEMBLY VIDEO MAY BE AVAILABLE ON OUR WEBSITE. IF NOT, THE VIDEO USED FOR THE V4500 IS VERY SIMILAR

TWIN BEAMS(#1) AND CRADLE TUBES(#2 & 2A) COME PRE-CABLED T & L CLAMPS ARE INSTALLED ON THE COLUMNS AT THE FACTORY

SEE PARTS LIST FOR ABOVE PART NUMBERS
DOCUMENT# A4MH-V45R12PARTS1LIST AND
DOCUMENT# A4MH-V35R12PARTS1LIST
DOCUMENT# A4MH-V25R12PARTS1LIST

READ MANUAL BEFORE USING HOIST.
Manual, parts list and drawing on the web WWW.CRAFTLANDER.COM

NOTE: WHEN ORDERING REPLACEMENT PARTS A SERIAL NUMBER WILL BE REQUIRED TO ENSURE RECEIPT OF CORRECT ITEMS



Rev	Date	Description	Int
		402 Southline Rd. Metal Products Roscommon, MI 48653	
Scale:	None	Approved by:	Drawn by: RLW
Date:	1/9/13		
		Assembly and part locations for V25108, V35108, V35120, V45108, V45114, & V45120 year 2012	
		Drawing Number A-MH-V25545R12	